



FRONT / FRONTWALL

| Model | A1 | X1 | D | H |
|---------|------|-----------|-----|------|
| DWD 140 | 1400 | 1390-1410 | 515 | 1900 |
| DWD 150 | 1500 | 1490-1510 | 515 | 1900 |
| DWD 160 | 1600 | 1590-1610 | 615 | 1900 |
| DWD 180 | 1800 | 1790-1810 | 715 | 1900 |

**ŚCIANKA S /
SIDEWALL S**

| Model | A2 | X2 |
|-------|------|----------|
| S 75 | 750 | 745-755 |
| S 80 | 800 | 795-805 |
| S 90 | 900 | 895-905 |
| S 100 | 1000 | 995-1005 |

